


**CAUTION: THIS EQUIPMENT  
MUST BE LOCKED OUT  
DURING MAINTENANCE OR  
ANY OPERATOR  
ADJUSTMENT.**



**NOTE: WIRING SHOWN FOR STANDARD "SOURCING" LOGIC.**