

## MACHINE MODELS

CAT 365B "V", "W"

DEERE 600C LC

HITACHI EX550LC-5, ZX600LC

KOMATSU PC600LC-6

NEW HOLLAND EC600




### SAFETY FIRST



1. Wear Safety Equipment.
2. Keep hands and feet clear.
3. Beware of flying objects.

Prior to removing any pins or parts refer to Manufacturers Service manual for proper procedures for securing and stabilizing equipment.



Item	Description
1	Bucket Teeth
2	Bucket to Linkage Pin
3	Bucket to Stick Pin
4	Stick Linkage Pin
5	Bucket Cylinder Rod End to Linkage
6	Bucket Cylinder Pin
7	Stick Cylinder Rod End Pin
8	Stick to Boom Pin
9	Stick Cylinder Pin
10	A. Boom to Frame (insert ONLY)
	B. Boom Cylinder Rod End

See back for Pin Removal / Insertion specifications and recommended Slide Sledge® tool kit.

The following removal and insertion tips are manufacturer recommendations for this model. Other model excavators may use similar tips and tools for similar removals. Consult with manufacturer for specific models and uses.

Item	Tool/Tip	Description	Part#
#1	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3/4" Bucket Tooth Remover	213302
	R/I Tip	3/4" Bucket Tooth Insertter	213301
#2	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#3	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#4	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#5	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#6	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#7	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#8	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#9	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106
#10	R/I Tool	21 lb./46" Slide Sledge	211401
	R/I Tip	3" Pin Driver	213106

**Recommended Tool Kit for 60 Ton Class Excavators**

Product	Part#
21 lb./46" Slide Sledge	211401
3" Pin Driver	213106
3/4" Bucket Tooth Remover	213302
3/4" Bucket Tooth Insertter	213301
Utility Wedge Tip	213528
5 lb. Handle Weight	211808

Removal and installation should only be performed on pins that have been properly serviced and maintained.